



Assembly instruction	62200432
Cable trolley system- Support arm	Valid from: 2013-08-09

Assembly instruction for support arm for I-Beam

To put up one support arm on an I-Beam you need the following:

- 1 pc. Support arm. 62200432
- 2 pcs. Girder Clip. 62200433
- 1 pc. Support bracket. 62200427

You can put the arm either on top of the beam or underneath the I-beam. The most common is to put it on top of the I-beam.

Take the support arm with the holes on it closest to the I-beam. Take the two girder clips and slide in the square nuts on the girder clips into the slot of the support arm.

The girder clips now form a clamp. Put the support arm with the girder clip clamp on top of the I-beam with one girder clip on each side of the I-beam "wings". Tighten the screws on the girder clips and the support arm is secured to the I-beam.

If you wish to put the support arm underneath the I-beam (not so common) you take the screws of the girder clips and put them through the most appropriate holes in the support arm.

Now take the support bracket, release the bolts a bit. Slide it in the slot of the support arm with the square nuts inside. Put in the C-rail that you use into the clamp of the support bracket and tighten the bolts.

Done!



Elaborated by: PSM: S. Scheiter	Document: Assembly instruction_62200432_EN	Sheet 1 of 1
------------------------------------	--	--------------